Transport and storage instructions

Transport

1. SALEP rectangular blade dampers must be handled during transport in such a way that no damage is caused to the packaging or the products.

2. Pallets must be lifted either by forklift or using lifting slings placed under the pallets.

3. If necessary, use extension forks on the forklift.

4. Loading on top of the blade dampers is prohibited.

5. When moving pallets after the straps have been removed, ensure that the shut-off dampers in the stack do not move.



Lifting instructions for forklifts

1. Ensure that the forklift's forks are long enough.

Ensure that the forklift's forks pass completely through the pallet. When using short forks, the tip of the fork must rest on the bottom boarding. The forks must extend to the other side of the pallet to ensure the load remains stable.

2. Do not lift if the forks are too short.

Do not lift the pallet if the forks are too short. Forks that are too short increase the risk of tipping and the load falling.

3. Ensure that the weight is distributed evenly.

Before lifting, ensure that the weight is distributed evenly across the pallet. An unevenly distributed load may cause instability during transport.

Storage and weather protection

1. Products and packaging must be transported protected from the weather.

2. The product may be stored outdoors, but any packaging that has become wet must be opened to allow the product to dry.

Installation

1. Check that the unit is in working order before installation.
2. The louvres are fitted to air-handling units or rectangular ducts using push-fit strips. For circular connections, use a sealed connector.

Lindab®